


# Peavey Ultra Plus head - G-Major interface



Relay 1 open and Relay 2 open = Ultra ch.  
Relay 1 open and Relay 2 closed = Crunch ch.

Relay 1 closed and Relay 2 open = Clean ch.  
Relay 1 closed and Relay 2 closed = Clean ch.

Please note:

If remote selection is desired,  
the Channel switch on the amp must be in the "in" (Ultra) position.

NB.

It is not possible to make the logo change to red in order to show  
Ultra mode with the G-Major.

with thanks to Hans Nielsen  
/ NSM, TC Electronic 030318